nVent LENTON Form Saver Assemblies (North America)

nVent LENTON Form Saver assemblies are 2-piece assemblies designed for segmental pour construction methods. The tapered threaded coupler is factory attached to the rebar either by friction welding or a nVent LENTON taper threaded connection. A separate rebar (dowel) is provided with matching external tapered threads.

nVent LENTON Form Saver assemblies are shipped from regional locations where nailer plates are installed along with temporary thread protection. The nailer plates are factory installed to ease the installation of nVent LENTON Form Saver's to existing concrete forms. The female coupler assembly is also furnished with short term thread protection.



Step 1: Ensure the nVent LENTON Form Saver is sized properly with project plans. Check and ensure proper installation of coupler thread protection prior to mounting to formwork.

Step 2: Install coupler assembly parallel with rebar to be spliced (Figure 1). Position nailer plate flush to form. Attach plate using nails, etc. Complete the tying off of the rebar. Ensure that assembly is properly supported to prevent movement before or during the pour. WARNING: The nailer flange is **NOT** intended to support the weight of rebar, installer or equipment.

Step 3: After forms are stripped, ensure that thread protection on couplers are removed prior to installation of male dowel (Figure 2).



Figure 1



[1111	Ø		700.e
inlb.	Metric	Canada	Nm	ftlb.
#3	10		40	30
#4	12	10M	40	30
	14		80	60
#5	16	15M	120	90
-	18		150	110
#6	20	20M	180	130
#7	22		220	160
-	24		270	200
#8	25	25M	270	200
	26	26M	270	200
#9	28	30M	270	200
_	30		300	200*
#10	32		300	200*
_	34		300	200*
#11	36	35M	300	200*

+Metric and imperial table values are not a direct conversion.

*Americas only









LENTON

Figure 2

Figure 3 Figure 4

Step 4: NOTE! Ensure that the correct nVent LENTON taper threaded rebar is utilized. Ensure dowel thread protection is removed. Ensure that the coupler and rebar dowel threads are clean and free of rust, concrete slurry, etc. (Figure 3). Clean as required using wire brush. Install rebar dowel hand tight, approx. 4-1/2 turns clockwise. Use a pipe wrench to tighten securely (Figure 4). Refer to Table 1 for torque required to complete installation. The nVent LENTON brand of inspection wrench can be used by inspectors to periodically check tightness.

Step 5: If the coupler and/or rebar is epoxy coated, refer to "Field Touch Up Recommendations for Epoxy Coated Couplers" Instruction Sheet PDF056. Additional copies of instructions and application information are available at www.nVent.com.

WARNING

nVent products shall be installed and used only as indicated in nVent product instruction sheets and training materials. Instruction sheets are available at www.nVent.com and from your nVent customer service representative.

nVent products must never be used for a purpose other than the purpose for which they were designed or in a manner that exceeds specified load ratings.

All instructions must be <u>completely</u> followed to ensure proper and safe installation and performance.

Improper installation, misuse, misapplication or other failure to completely follow nVent's instructions and warnings may cause product malfunction, property damage, serious bodily injury and/or death, and void your warranty.

The customer is responsible for:

a. Conformance to all governing codes.
b. The integrity of structures to which the products are attached, including their capability of safely accepting the loads imposed, as evaluated by a qualified engineer.

All governing codes and regulations and those required by the job site must be observed. Always use appropriate safety equipment such as eye protection, hard hat, and gloves as appropriate to the application.

nVent, nVent CADDY, nVent ERICO Cadweld, nVent ERICO Critec, nVent ERICO, nVent ERIFLEX, and nVent LENTON are registered trademarks of nVent or its global affiliates. All other trademarks are the property of their respective owners, nVent reservers the right to change specifications without prior notice.



c. Using appropriate industry standard hardware as noted above.