


# CADWELD<sup>®</sup>

## Rail Web Extension Clamp



Prior to making a connection, read and follow the full instruction sheet (IPRPW) shipped with CADWELD mold and special instructions below.

- 1) Clean and prepare the contact surface of the bond area.
- 2) Adjust welder so that the mold is held firmly against the rail as shown.  
 Note: The mold should seat against the rail contour with no excessive gaps.  
 If mold does not seat, rub back and forth until proper seating is attained.
- 3) Follow welding procedure outlined in IPRSW

**WARNING:**

1. ERICO products shall be installed and used only as indicated in ERICO product instruction sheets and training materials. Instruction sheets are available at [www.erico.com](http://www.erico.com) and from your ERICO customer service representative.
2. ERICO products must never be used for a purpose other than the purpose for which they were designed or in a manner that exceeds specified load ratings.
3. All instructions must be **completely** followed to ensure proper and safe installation and performance.
4. Improper installation, misuse, misapplication or other failure to completely follow ERICO's instructions and warnings may cause product malfunction, property damage, serious bodily injury and death.

**SAFETY INSTRUCTIONS:**

All governing codes and regulations and those required by the job site must be observed. Always use appropriate safety equipment such as eye protection, hard hat, and gloves as appropriate to the application.

CADDY, CADWELD, CRITEC, ERICO, ERITECH, ERIFLEX, and LENTON are registered trademarks of ERICO International Corporation.